

# CROSS REFERENCE TRANSMISSIONS



ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER
<b>FORD</b>		<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>	
1C2P-7000-AA	1C2Z-7000-ACRM	1L3P-7000-AA	1L3Z-7000-ACRM	91GT-7000-AED	F19Z-7V000-ARM	93GT-7000-MAB	F37Z-7V000-MARM
1C2P-7000-AB	1C2Z-7000-ACRM	1L3P-7000-AB	1L3Z-7000-ACRM	91GT-7000-BAA	F17Z-7V000-BRM	93GT-7000-MBA	F39Z-7V000-MBRM
1C2P-7000-AC	1C2Z-7000-ACRM	1L3P-7000-AC	1L3Z-7000-ACRM	91GT-7000-BAB	F17Z-7V000-BRM	93GT-7000-MBB	F39Z-7V000-MBRM
1C2P-7000-BA	1C2Z-7000-BCRM	1L3P-7000-BA	1L3Z-7000-BCRM	91GT-7000-DAB	F17Z-7V000-DARM	93GT-7000-NAA	F37Z-7V000-NRM
1C2P-7000-BB	1C2Z-7000-BCRM	1L3P-7000-BB	1L3Z-7000-BCRM	91GT-7000-DAB	F17Z-7V000-DARM	93GT-7000-NAB	F37Z-7V000-NRM
1C2P-7000-BC	1C2Z-7000-BCRM	1L3P-7000-BC	1L3Z-7000-BCRM	91GT-7000-EAA	F17Z-7V000-ERM	93GT-7000-NBA	F39Z-7V000-NRM
1C2P-7000-CA	1C2Z-7000-CCRM	1L3P-7000-CA	1L3Z-7000-CCRM	91GT-7000-EAB	F17Z-7V000-ERM	93GT-7000-NBC	F39Z-7V000-NRM
1C2P-7000-CB	1C2Z-7000-CCRM	1L3P-7000-CB	1L3Z-7000-CCRM	91GT-7000-GAA	F19Z-7V000-GARM	93GT-7000-RAA	F37Z-7V000-RARM
1C2P-7000-CC	1C2Z-7000-CCRM	1L3P-7000-CC	1L3Z-7000-CCRM	91GT-7000-HAA	F19Z-7V000-HRM	93GT-7000-RAB	F37Z-7V000-RARM
1C2P-7000-DA	1C2Z-7000-DBRM	1L3P-7000-DA	1L3Z-7000-DARM	91GT-7000-SAA	F19Z-7V000-GARM	93GT-7000-SAA	F37Z-7V000-SRM
1C2P-7000-DB	1C2Z-7000-DBRM	1L3P-7000-DB	1L3Z-7000-DARM	91GT-7000-SBA	F19Z-7V000-HRM	93GT-7000-SAB	F37Z-7V000-SRM
1C2P-7000-EA	1C2Z-7000-EBRM	1L3P-7000-EA	1L3Z-7000-EARM	91GT-7000-SCA	F19Z-7V000-SERM	93GT-7000-SBB	F37Z-7V000-SBRM
1C2P-7000-EB	1C2Z-7000-EBRM	1L3P-7000-EA	1L3Z-7000-EARM	91GT-7000-SDA	F19Z-7V000-SRM	93GT-7000-SBC	F37Z-7V000-SBRM
1C2P-7000-FA	1C2Z-7000-FARM	1L3P-7000-FA	1L3Z-7000-FARM	91GT-7000-SEA	F19Z-7V000-SERM	93GT-7000-TAA	F39Z-7V000-FBRM
1C2P-7000-HA	1C2Z-7000-HARM	1L3P-7000-JA	1L3Z-7000-JARM	91GT-7000-SFA	F19Z-7V000-SRM	93GT-7000-JAA	F29Z-7V000-GRM
1C2P-7000-JA	1C2Z-7000-JARM	1L3P-7000-LA	1L3Z-7000-LARM	92GT-7000-ABA	F27Z-7V000-ABRM	95GT-7000-AAA	F57Z-7V000-HARM
1C2P-7000-LA	1C2Z-7000-LARM	1L5P-7000-AA	1L5Z-7000-AARM	92GT-7000-ADA	F39Z-7V000-FBRM	95GT-7000-BAA	F57Z-7V000-KARM
1C2P-7000-MA	1C2Z-7000-MARM	1L5P-7000-BA	1L5Z-7000-BARM	92GT-7000-AEA	F29Z-7V000-GRM	95GT-7000-CAA	F57Z-7V000-CARM
1C2P-7000-NA	1C2Z-7000-NCRM	1L5P-7000-CA	1L5Z-7000-CARM	92GT-7000-AFA	F39Z-7V000-FBRM	95GT-7000-DAA	F57Z-7V000-FARM
1C2P-7000-NB	1C2Z-7000-NCRM	1L5P-7000-DA	1L5Z-7000-DARM	92GT-7000-AGA	F29Z-7V000-GRM	95GT-7000-EAA	F57Z-7V000-GARM
1C2P-7000-NC	1C2Z-7000-NCRM	1L5P-7000-EA	1L5Z-7000-EARM	92GT-7000-AHA	F29Z-7V000-AHRM	95GT-7000-FAA	F68Z-7V000-DARM
1C3P-7000-AA	1C3Z-7000-ACRM	1L7P-7000-AA	1L7Z-7000-ACRM	92GT-7000-AKA	F29Z-7V000-ARM	95GT-7000-GAA	F68Z-7V000-EBRM
1C3P-7000-AB	1C3Z-7000-ACRM	1L7P-7000-AB	1L7Z-7000-ACRM	92GT-7000-ALA	F29Z-7V000-AHRM	95GT-7000-HAA	F39Z-7V000-FBRM
1C3P-7000-AC	1C3Z-7000-ACRM	1L7P-7000-AD	1L7Z-7000-ACRM	92GT-7000-AMA	F29Z-7V000-ARM	95GT-7000-HAA	F57Z-7V000-HARM
1C3P-7000-BA	1C3Z-7000-BCRM	1L7P-7000-BA	1L7Z-7000-BCRM	92GT-7000-ANA	F29Z-7V000-ANRM	95GT-7000-KAA	F29Z-7V000-GRM
1C3P-7000-BB	1C3Z-7000-BCRM	1L7P-7000-BB	1L7Z-7000-BCRM	92GT-7000-ARA	F29Z-7V000-BRM	95GT-7000-LAA	F39Z-7V000-FBRM
1C3P-7000-BC	1C3Z-7000-BCRM	1L7P-7000-BC	1L7Z-7000-BCRM	92GT-7000-ASA	F29Z-7V000-ANRM	95GT-7000-MAA	F29Z-7V000-GRM
1C3P-7000-CA	1C3Z-7000-CCRM	1R3P-7000-AA	1R3Z-7000-AARM	92GT-7000-ATA	F29Z-7V000-BRM	95GT-7000-MBA	F39Z-7V000-MBRM
1C3P-7000-CB	1C3Z-7000-CCRM	1R3P-7000-BA	1R3Z-7000-BARM	92GT-7000-CBA	F27Z-7V000-CBRM	95GT-7000-NBA	F39Z-7V000-NRM
1C3P-7000-CC	1C3Z-7000-CCRM	1S4P-7000-CA	1S4Z-7000-CARM	92GT-7000-CBB	F27Z-7V000-CBRM	95GT-7000-NBA	F39Z-7V000-NRM
1C3P-7000-DA	1C3Z-7000-DCRM	1S4P-7000-DA	1S4Z-7000-DARM	92GT-7000-CDA	F27Z-7V000-CRM	95GT-7000-RAA	F39Z-7V000-HBRM
1C3P-7000-DB	1C3Z-7000-DCRM	1S8P-7000-AA	1S8Z-7000-AARM	92GT-7000-CDB	F27Z-7V000-CRM	95GT-7000-SAA	F57Z-7V000-KRM
1C3P-7000-DC	1C3Z-7000-DCRM	1W1P-7000-AA	1W1Z-7000-AARM	92GT-7000-CEA	F27Z-7V000-CERM	96GT-7000-BAA	F69Z-7V000-BARM
1C3P-7000-EA	1C3Z-7000-EBRM	1W1P-7000-BA	1W1Z-7000-BARM	92GT-7000-CEB	F27Z-7V000-CERM	96GT-7000-CAA	F57Z-7V000-CARM
1C3P-7000-EB	1C3Z-7000-EBRM	1W1P-7000-CA	1W1Z-7000-CARM	92GT-7000-CFA	F27Z-7V000-DRM	96GT-7000-DBA	F68Z-7V000-EBRM
1C3P-7000-FA	1C3Z-7000-FBRM	1W1P-7000-DA	1W1Z-7000-DARM	92GT-7000-CFB	F27Z-7V000-DRM	96GT-7000-EBA	F68Z-7V000-EBRM
1C3P-7000-FB	1C3Z-7000-FBRM	1W4P-7000-AA	1W4Z-7000-AARM	93GT-7000-AAA	F37Z-7V000-AARM	96GT-7000-FAA	F57Z-7V000-FARM
1C3P-7000-HA	1C3Z-7000-HCRM	1W4P-7000-BA	1W4Z-7000-BARM	93GT-7000-ADD	F37Z-7V000-ADRM	96GT-7000-GAA	F57Z-7V000-GARM
1C3P-7000-HB	1C3Z-7000-HCRM	1W7P-7000-AA	1W7Z-7000-AARM	93GT-7000-ADE	F37Z-7V000-AERM	96GT-7000-KAA	F57Z-7V000-KARM
1C3P-7000-HC	1C3Z-7000-HCRM	1W7P-7000-BA	1W7Z-7000-AARM	93GT-7000-BAA	F37Z-7V000-BRM	96GT-7000-MAA	F69Z-7V000-MARM
1C3P-7000-JA	1C3Z-7000-JCRM	1W7P-7000-CA	1W7Z-7000-CARM	93GT-7000-BBA	F39Z-7V000-HBRM	96GT-7000-NAA	F69Z-7V000-NARM
1C3P-7000-JB	1C3Z-7000-JCRM	1W7P-7000-DA	1W7Z-7000-DARM	93GT-7000-BBB	F39Z-7V000-HBRM	97GT-7000-LEA	F77Z-7V000-LCRM
1C3P-7000-JC	1C3Z-7000-JCRM	2L2P-7000-AA	2L2Z-7000-AARM	93GT-7000-CAA	F37Z-7V000-CARM	97GT-7000-ACA	F77Z-7V000-AARM
1C3P-7000-KA	1C3Z-7000-KCRM	2L2P-7000-BA	2L2Z-7000-BARM	93GT-7000-CAB	F37Z-7V000-CARM	97GT-7000-AEA	F77Z-7V000-AARM
1C3P-7000-KB	1C3Z-7000-KCRM	2L2P-7000-CA	2L2Z-7000-CARM	93GT-7000-CBA	F39Z-7V000-KRM	97GT-7000-BEA	F77Z-7V000-BARM
1C3P-7000-KC	1C3Z-7000-KCRM	2L2P-7000-DA	2L2Z-7000-DARM	93GT-7000-CBB	F39Z-7V000-KRM	97GT-7000-CEA	F77Z-7V000-EARM
1C3P-7000-LA	1C3Z-7000-LBRM	2L5P-7000-AA	2L5Z-7000-ABRM	93GT-7000-DAA	F37Z-7V000-DRM	97GT-7000-FCA	F77Z-7V000-FARM
1C3P-7000-LB	1C3Z-7000-LBRM	2L5P-7000-BB	2L5Z-7000-BBRM	93GT-7000-DAB	F37Z-7V000-DRM	97GT-7000-GCA	F77Z-7V000-GARM
1C3P-7000-MA	1C3Z-7000-MBRM	2L5P-7000-CB	2L5Z-7000-CBRM	93GT-7000-DBA	F39Z-7V000-MBRM	97GT-7000-KCA	F77Z-7V000-KARM
1C3P-7000-MB	1C3Z-7000-MBRM	2L8P-7000-CA	2L8Z-7000-CBRM	93GT-7000-DBB	F39Z-7V000-MBRM	97GT-7000-KCA	F77Z-7V000-KCRM
1C3P-7000-NA	1C3Z-7000-NCRM	2L8P-7000-CB	2L8Z-7000-CBRM	93GT-7000-EAA	F37Z-7V000-EARM	97GT-7000-KDA	F77Z-7V000-KARM
1C3P-7000-NB	1C3Z-7000-NCRM	2L8P-7000-DA	2L8Z-7000-DBRM	93GT-7000-EAB	F37Z-7V000-EARM	97GT-7000-KFA	F77Z-7V000-KCRM
1C3P-7000-NC	1C3Z-7000-NCRM	2L8P-7000-DB	2L8Z-7000-DBRM	93GT-7000-EBA	F39Z-7V000-NRM	97GT-7000-KEA	F77Z-7V000-KARM
1C3P-7000-PA	1C3Z-7000-PCRM	2L8P-7000-EB	2L8Z-7000-EBRM	93GT-7000-EBB	F39Z-7V000-NRM	97GT-7000-KFA	F77Z-7V000-KCRM
1C3P-7000-PB	1C3Z-7000-PCRM	2L8P-7000-FA	2L8Z-7000-FBRM	93GT-7000-FAA	F37Z-7V000-FRM	97GT-7000-LCA	F77Z-7V000-LARM
1C3P-7000-PC	1C3Z-7000-PCRM	2L8P-7000-FB	2L8Z-7000-FBRM	93GT-7000-FAB	F37Z-7V000-FRM	97GT-7000-LDA	F77Z-7V000-LCRM
1F1P-7000-AA	1F1Z-7000-AARM	2W4P-7000-AA	2W4Z-7000-AARM	93GT-7000-FBA	F39Z-7V000-FBRM	97GT-7000-LFA	F77Z-7V000-LARM
1F1P-7000-CB	1F1Z-7000-CBRM	2W4P-7000-BA	2W4Z-7000-BARM	93GT-7000-GAA	F37Z-7V000-GARM	97GT-7000-MCA	F77Z-7V000-MARM
1F1P-7000-DB	1F1Z-7000-DBRM	88GT-7000-LAA	E89Z-7V000-LARM	93GT-7000-GAB	F37Z-7V000-GARM	97GT-7000-NCA	F77Z-7V000-NARM
1F1P-7000-EB	1F1Z-7000-EBRM	88GT-7000-LAB	E89Z-7V000-LARM	93GT-7000-GBA	F29Z-7V000-GRM	97GT-7000-RCA	F77Z-7V000-RARM
1F1P-7000-FB	1F1Z-7000-FBRM	88GT-7000-MAB	E89Z-7V000-MARM	93GT-7000-HAA	F37Z-7V000-HRM	97GT-7000-REA	F77Z-7V000-RARM
1F1P-7000-GA	1F1Z-7000-GARM	89GT-7000-EAB	E99Z-7V000-EARM	93GT-7000-HAB	F37Z-7V000-HRM	97GT-7000-SCA	F77Z-7V000-SARM
1F2P-7000-CC	1F2Z-7000-CCRM	89GT-7000-GAB	E99Z-7V000-GRM	93GT-7000-HBA	F39Z-7V000-HBRM	97GT-7000-SEA	F77Z-7V000-SARM
1F3P-7000-AB	1F3Z-7000-ABRM	89GT-7000-TAB	E99Z-7V000-EARM	93GT-7000-HBC	F39Z-7V000-HBRM	97GT-7000-TAA	F77Z-7V000-TARM
1F3P-7000-AC	1F3Z-7000-ACRM	89GT-7000-TBB	E99Z-7V000-GRM	93GT-7000-KAA	F37Z-7V000-KARM	98GT-7000-KBA	F87Z-7V000-KARM
1F3P-7000-BB	1F3Z-7000-BBRM	90GT-7000-RAA	F19Z-7V000-AERM	93GT-7000-KAB	F37Z-7V000-KARM	98GT-7000-LAA	F87Z-7V000-LARM
1F3P-7000-BC	1F3Z-7000-BCRM	90GT-7000-RBA	F19Z-7V000-AERM	93GT-7000-KBA	F39Z-7V000-KRM	98GT-7000-AAA	F87Z-7V000-DARM
1L1P-7000-AA	1L1Z-7000-ACRM	91GT-7000-AAA	F17Z-7V000-AARM	93GT-7000-KBB	F39Z-7V000-KRM	98GT-7000-CBA	F87Z-7V000-FARM
1L1P-7000-AB	1L1Z-7000-ACRM	91GT-7000-AAB	F17Z-7V000-AARM	93GT-7000-LAA	F37Z-7V000-LRM	98GT-7000-DBA	F87Z-7V000-EARM
1L1P-7000-AC	1L1Z-7000-ACRM	91GT-7000-AEB	F19Z-7V000-ARM	93GT-7000-LAB	F37Z-7V000-LRM	98GT-7000-EAA	F87Z-7V000-JARM
1L2P-7000-AE	1L2Z-7000-AERM	91GT-7000-AEC	F19Z-7V000-ARM	93GT-7000-LBA	F37Z-7V000-LARM	98GT-7000-EBA	F87Z-7V000-JARM
1L2P-7000-BE	1L2Z-7000-BERM			93GT-7000-LBB	F37Z-7V000-LARM	98GT-7000-FAA	F87Z-7V000-HARM
1L2P-7000-CE	1L2Z-7000-CERM			93GT-7000-LBC	F37Z-7V000-LARM	98GT-7000-FBA	F87Z-7V000-HARM
1L2P-7000-DE	1L2Z-7000-DERM					98GT-7000-GAA	F87Z-7V000-GARM

FOR REFERENCE PURPOSES ONLY - CHECK VEHICLE APPLICATION LISTING FOR SPECIFIC MOTORCRAFT PART NUMBER



**GENUINE PARTS**



**Motorcraft**

# CROSS REFERENCE TRANSMISSIONS

ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER
<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>	
98GT-7000-KAA	F87Z-7000-KARM	F2TP-7000-AHA	F2TZ-7V000-AHRM	F4UP-7000-CA	F4UZ-7V000-CRM	F6UP-7000-FA	F6UZ-7V000-FARM
98GT-7000-LAA	F87Z-7000-LARM	F2TP-7000-BA	F2TZ-7V000-BRM	F58P-7000-AA	F58Z-7V000-ARM	F6UP-7000-GA	F6UZ-7V000-GARM
98GT-7000-LBA	F87Z-7000-LARM	F2TP-7000-CA	F2TZ-7V000-CRM	F5AP-7000-AA	F5AZ-7V000-ARM	F6UP-7000-HA	F6UZ-7V000-HARM
E7DP-7000-CB	E7DZ-7V000-CBRM	F2TP-7000-DA	F2TZ-7V000-DRM	F5AP-7000-BA	F5AZ-7V000-BRM	F6UP-7000-JA	F6UZ-7V000-JARM
E83P-7000-BA	F03Z-7000-FRM	F2TP-7000-EA	F2TZ-7V000-ERM	F5C6-7000-AB	F5CZ-7000-ARM	F6UP-7000-KA	F6UZ-7V000-KARM
E8DP-7000-AA	E8DZ-7V000-ARM	F2TP-7000-FA	F2TZ-7V000-FRM	F5DP-7000-AA	F5DZ-7V000-AARM	F6UP-7000-LA	F6UZ-7V000-LARM
E8DP-7000-BA	E8DZ-7V000-BARM	F2TP-7000-HA	F2TZ-7V000-HRM	F5DP-7000-BA	F5DZ-7V000-BARM	F6ZP-7000-BB	F6ZZ-7V000-BBRM
E8DP-7000-CA	E8DZ-7000-CRM	F2TP-7000-JA	F2TZ-7V000-JRM	F5DP-7000-CA	F5DZ-7V000-CARM	F6ZP-7000-CA	F6ZZ-7000-CARM
E8DP-7000-DA	F0DZ-7V000-BARM	F2TP-7000-LA	F2TZ-7V000-LRM	F5DP-7000-HA	F5DZ-7V000-HRM	F73P-7000-AB	F83Z-7000-CBRM
E8DP-7000-EA	F0DZ-7V000-AARM	F2TP-7000-MA	F2TZ-7V000-MRM	F5LP-7000-AB	F5LY-7V000-ARM	F73P-7000-BB	F83Z-7000-DBRM
E9DP-7000-BA	F0DZ-7V000-BARM	F2TP-7000-NA	F2TZ-7V000-NRM	F5OP-7000-BA	F5OZ-7V000-BRM	F75P-7000-AA	F75Z-7V000-ARM
E9DP-7000-CA	F0DZ-7V000-AARM	F2TP-7000-NA	F2TZ-7V000-NRM	F5OP-7000-DA	F5OZ-7V000-DRM	F75P-7000-DA	F75Z-7V000-DRM
E9OP-7000-AA	F0OZ-7V000-AARM	F2TP-7000-PA	F2TZ-7V000-PRM	F5RP-7000-AA	F5RZ-7V000-ARM	F75P-7000-EA	F75Z-7V000-ERM
E9TP-7000-AA	E9TZ-7V000-ARM	F2TP-7000-SA	F2TZ-7V000-SRM	F5RP-7000-AB	F5RZ-7V000-ARM	F75P-7000-FA	F75Z-7V000-FRM
E9TP-7000-BDA	E9TZ-7V000-BDRM	F2UP-7000-DA	F2TZ-7V000-DRM	F5RP-7000-AC	F5RZ-7V000-ARM	F75P-7000-GA	F75Z-7V000-GRM
E9TP-7000-BEA	E9TZ-7V000-BERM	F2UP-7000-DC	F2TZ-7V000-BRM	F5RP-7000-BA	F5RZ-7V000-BRM	F75P-7000-HA	F75Z-7V000-HRM
E9TP-7000-BFA	E9TZ-7V000-BFRM	F2UP-7000-EA	F2TZ-7V000-FRM	F5SP-7000-AA	F5SZ-7V000-ARM	F75P-7000-JA	F75Z-7V000-JRM
E9TP-7000-CA	E9TZ-7V000-CRM	F2UP-7000-EB	F2TZ-7V000-ERM	F5SP-7000-BA	F5SZ-7V000-BRM	F75P-7000-KA	F75Z-7V000-KRM
E9TP-7000-CB	E9TZ-7V000-CRM	F2UP-7000-EC	F2TZ-7V000-FRM	F5TP-7000-AB	F5TZ-7V000-ARM	F75P-7000-LA	F75Z-7V000-LBRM
E9TP-7000-EA	E9TZ-7V000-ERM	F2UP-7000-GA	F2TZ-7V000-JRM	F5TP-7000-BB	F5TZ-7V000-BRM	F75P-7000-LA	F75Z-7V000-LRM
E9TP-7000-EB	E9TZ-7V000-ERM	F2UP-7000-HA	F2TZ-7V000-NRM	F5TP-7000-CB	F5TZ-7V000-CRM	F75P-7000-LB	F75Z-7V000-LBRM
E9TP-7000-FA	E9TZ-7V000-FRM	F2UP-7000-HC	F2TZ-7V000-NRM	F5TP-7000-DB	F5TZ-7V000-DRM	F75P-7000-LB	F75Z-7V000-LBRM
E9TP-7000-GA	E9TZ-7V000-GRM	F2UP-7000-MA	F2UZ-7V000-MRM	F5TP-7000-EB	F5TZ-7V000-ERM	F75P-7000-MA	F75Z-7V000-MRM
E9TP-7000-GB	E9TZ-7V000-GRM	F2UP-7000-NA	F2TZ-7V000-NRM	F5TP-7000-GB	F5TZ-7V000-GRM	F75P-7000-MB	F75Z-7V000-MRM
E9TP-7000-HA	E9TZ-7V000-HRM	F2UP-7000-NA	F2UZ-7V000-NRM	F5TP-7000-HB	F5TZ-7V000-HRM	F77P-7000-AA	F77Z-7V000-ARM
E9TP-7000-HB	E9TZ-7V000-HRM	F3DP-7000-AC	F3DZ-7V000-ARM	F5TP-7000-JB	F5TZ-7V000-JRM	F77P-7000-BB	F77Z-7V000-BRM
E9TP-7000-JA	E9TZ-7V000-JRM	F3DP-7000-BB	F3DZ-7V000-BRM	F5TP-7000-LB	F5TZ-7V000-LRM	F78P-7000-AA	F78Z-7V000-ARM
E9TP-7000-LA	E9TZ-7V000-LRM	F3DP-7000-CB	F3DZ-7V000-CRM	F5UP-7000-BB	F5UZ-7V000-BRM	F78P-7000-BA	F78Z-7V000-BRM
E9TP-7000-LB	E9TZ-7V000-LRM	F3DP-7000-DB	F3DZ-7V000-DRM	F5UP-7000-CB	F5UZ-7V000-CRM	F7AP-7000-AA	F7AZ-7V000-ARM
E9TP-7000-NA	E9TZ-7V000-NRM	F3LP-7000-BA	F5LY-7V000-ARM	F5UP-7000-DB	F5UZ-7V000-DRM	F7AP-7000-BA	F7AZ-7V000-BRM
F0OP-7000-AA	F0OZ-7V000-AARM	F3TP-7000-DB	F3TZ-7V000-DRM	F5UP-7000-EB	F5UZ-7V000-ERM	F7AP-7000-CA	F7AZ-7V000-CRM
F03P-7000-BA	F03Z-7000-HRM	F3TP-7000-EA	F3TZ-7V000-DRM	F5UP-7000-FB	F5UZ-7V000-FRM	F7AP-7000-DA	F7AZ-7V000-ARM
F03P-7000-FA	F03Z-7000-FRM	F3TP-7000-EB	F3TZ-7V000-DRM	F5UP-7000-GB	F5UZ-7V000-GRM	F7AP-7000-GA	F7AZ-7V000-BRM
F0DP-7000-AA	F0DZ-7V000-AARM	F3TP-7000-GA	F3TZ-7V000-DRM	F5UP-7000-HB	F5UZ-7V000-HRM	F7DP-7000-AA	F7DZ-7V000-ARM
F0DP-7000-BA	F0DZ-7V000-BARM	F3TP-7000-LA	F3TZ-7V000-LRM	F63P-7000-AA	F63Z-7V000-ARM	F7DP-7000-BA	F7DZ-7V000-BRM
F0DP-7000-CA	F0DZ-7V000-BARM	F3TP-7000-MA	F3TZ-7V000-MRM	F63P-7000-AB	F63Z-7V000-CRM	F7DP-7000-CA	F7DZ-7V000-CRM
F0TP-7000-AA	F0TZ-7V000-ARM	F3UP-7000-BA	F3UZ-7V000-BRM	F63P-7000-BA	F63Z-7V000-BRM	F7DP-7000-DA	F7DZ-7V000-DRM
F0TP-7000-ACA	F0TZ-7V000-LRM	F3UP-7000-CA	F3UZ-7V000-CRM	F63P-7000-BB	F63Z-7V000-BRM	F7DP-7000-EA	F7DZ-7V000-ERM
F0TP-7000-BA	F0TZ-7V000-BRM	F3UP-7000-DA	F3UZ-7V000-DRM	F63P-7000-BC	F63Z-7V000-BRM	F7LP-7000-AA	F7LZ-7V000-ARM
F0TP-7000-BB	F0TZ-7V000-BRM	F3UP-7000-EA	F3UZ-7V000-ERM	F65P-7000-AA	F65Z-7V000-AARM	F7OP-7000-AA	F7OZ-7V000-ARM
F0TP-7000-EA	F0TZ-7V000-ERM	F3UP-7000-FA	F3UZ-7V000-FRM	F65P-7000-CA	F65Z-7V000-CARM	F7OP-7000-BA	F7OZ-7V000-BRM
F0TP-7000-FA	F0TZ-7V000-FRM	F43P-7000-FC	F43Z-7V000-FRM	F65P-7000-DA	F65Z-7V000-DARM	F7RP-7000-AA	F7RZ-7V000-ARM
F0TP-7000-GA	F0TZ-7V000-GRM	F43P-7000-FD	F43Z-7V000-FRM	F65P-7000-EA	F65Z-7V000-EARM	F7RP-7000-AB	F7RZ-7V000-BRM
F0TP-7000-HA	F0TZ-7V000-HRM	F43P-7000-FE	F43Z-7V000-FRM	F67P-7000-AA	F67Z-7V000-AARM	F7SP-7000-AA	F6SZ-7V000-AARM
F0TP-7000-NA	F0TZ-7V000-NRM	F48P-7000-BB	F48Z-7V000-BRM	F67P-7000-BB	F67Z-7V000-BBRM	F7TP-7000-HA	F7TZ-7V000-HRM
F0TP-7000-PA	F0TZ-7V000-PRM	F48P-7000-BA	F48Z-7V000-CRM	F68P-7000-AA	F68Z-7V000-AARM	F7TP-7000-JA	F7TZ-7V000-JRM
F0TP-7000-RA	F0TZ-7V000-RRM	F4DP-7000-AA	F5DZ-7V000-HRM	F68P-7000-BA	F68Z-7V000-BARM	F7TP-7000-KA	F7TZ-7V000-KRM
F0TP-7000-SA	F0TZ-7V000-SRM	F4DP-7000-AB	F5DZ-7V000-HRM	F6AP-7000-AA	F6AZ-7V000-AARM	F7TP-7000-LA	F7TZ-7V000-LRM
F0TP-7000-TA	F0TZ-7V000-TRM	F4DP-7000-AC	F5DZ-7V000-HRM	F6AP-7000-BA	F6AZ-7V000-BARM	F7TP-7000-MA	F7TZ-7V000-MRM
F0TP-7000-UA	F0TZ-7V000-URM	F4DP-7000-BA	F4DZ-7V000-BRM	F6DP-7000-AA	F6DZ-7V000-AARM	F7TP-7000-NA	F7TZ-7V000-NARM
F0TP-7000-VA	F0TZ-7V000-VRM	F4DP-7000-BB	F4DZ-7V000-BRM	F6DP-7000-EA	F6DZ-7V000-EARM	F7TP-7000-PA	F7TZ-7V000-PRM
F0TP-7000-WA	F0TZ-7V000-LRM	F4DP-7000-CA	F4DZ-7V000-CRM	F6LP-7000-AA	F6LZ-7V000-AARM	F7TP-7000-RA	F7TZ-7V000-RRM
F0TP-7000-YA	F0TZ-7V000-YRM	F4DP-7000-CA	F4DZ-7V000-CRM	F6OP-7000-AA	F6OZ-7V000-AARM	F7TP-7000-TA	F7TZ-7V000-TARM
F0TP-7000-ZA	F0TZ-7V000-ZRM	F4DP-7000-DB	F4DZ-7V000-DRM	F6OP-7000-BA	F6OZ-7V000-BARM	F7TP-7000-UA	F7TZ-7V000-UARM
F0UP-7000-EA	F0TZ-7V000-ERM	F4DP-7000-DB	F4DZ-7V000-DRM	F6RP-7000-AA	F6RZ-7V000-ARM	F7UP-7000-AA	F7UZ-7V000-ARM
F0UP-7000-FA	F0TZ-7V000-FRM	F4DP-7000-EB	F4DZ-7V000-ERM	F6RP-7000-AB	F6RZ-7V000-ARM	F7UP-7000-BA	F7UZ-7V000-BRM
F0UP-7000-GA	F0TZ-7V000-GRM	F4DP-7000-EB	F4DZ-7V000-ERM	F6SP-7000-AA	F6SZ-7V000-AARM	F7UP-7000-CA	F7UZ-7V000-CRM
F0UP-7000-HA	F0TZ-7V000-ARM	F4LP-7000-AA	F5LY-7V000-ARM	F6SP-7000-BA	F6SZ-7V000-BARM	F7UP-7000-EA	F7UZ-7V000-ERM
F0UP-7000-JA	F0TZ-7V000-PRM	F4OP-7000-BA	F4OZ-7V000-BRM	F6TP-7000-AA	F6TZ-7V000-AARM	F7UP-7000-HA	F7UZ-7V000-HRM
F0UP-7000-KA	F0TZ-7V000-PRM	F4OP-7000-BB	F4OZ-7V000-BRM	F6TP-7000-BA	F6TZ-7V000-BARM	F7UP-7000-JA	F7UZ-7V000-JRM
F0UP-7000-LA	F0TZ-7V000-LRM	F4RP-7000-AB	F5RZ-7V000-BRM	F6TP-7000-CA	F6TZ-7V000-CARM	F7UP-7000-NA	F7UZ-7V000-NRM
F0UP-7000-MA	F0TZ-7V000-LRM	F4RP-7000-BC	F5RZ-7V000-ARM	F6TP-7000-DA	F6TZ-7V000-DARM	F7UP-7000-PA	F7UZ-7V000-PRM
F0UP-7000-NA	F0TZ-7V000-RRM	F4RP-7000-FD	F5RZ-7V000-ARM	F6TP-7000-EA	F6TZ-7V000-EARM	F7UP-7000-TA	F7UZ-7V000-TARM
F1DP-7000-BA	F1DZ-7V000-BRM	F4SP-7000-BB	F4SZ-7V000-BRM	F6TP-7000-FA	F6TZ-7V000-FARM	F7UP-7000-XA	F7UZ-7V000-XARM
F1DP-7000-CA	F1DZ-7V000-CRM	F4SP-7000-CA	F4SZ-7V000-BRM	F6TP-7000-GA	F6TZ-7V000-GARM	F81P-7000-AB	F81Z-7000-ABRM
F1DP-7000-DA	F1DZ-7V000-DRM	F4SP-7000-DA	F4SZ-7V000-ARM	F6TP-7000-HA	F6TZ-7V000-HARM	F81P-7000-BB	F81Z-7000-BBRM
F1TP-7000-LA	F0TZ-7V000-LRM	F4TP-7000-AA	F4TZ-7V000-ARM	F6TP-7000-JA	F6TZ-7V000-JARM	F81P-7000-DB	F81Z-7000-DBRM
F1TP-7000-MA	F0TZ-7V000-BRM	F4TP-7000-BA	F4TZ-7V000-BRM	F6TP-7000-KA	F6TZ-7V000-KARM	F81P-7000-EB	F81Z-7000-EBRM
F1TP-7000-NA	F0FZ-7V000-ARM	F4TP-7000-CA	F4TZ-7V000-CRM	F6UP-7000-AA	F6UZ-7V000-AARM	F81P-7000-FB	F81Z-7000-FBRM
F2DP-7000-BA	F2DZ-7V000-BRM	F4TP-7000-EA	F4TZ-7V000-ERM	F6UP-7000-BA	F6UZ-7V000-BARM	F81P-7000-FB	F81Z-7000-FBRM
F2DP-7000-CA	F2DZ-7V000-CRM	F4TP-7000-FA	F4TZ-7V000-FRM	F6UP-7000-CA	F6UZ-7V000-CARM	F81P-7000-FB	F81Z-7000-FBRM
F2DP-7000-DA	F2DZ-7V000-DRM	F4TP-7000-MA	F4TZ-7V000-MRM	F6UP-7000-DA	F6UZ-7V000-DARM	F81P-7000-HB	F81Z-7000-HBRM
F2TP-7000-ACA	F2FZ-7V000-ARM	F4UP-7000-AA	F4UZ-7V000-ARM	F6UP-7000-DA	F6UZ-7V000-DARM	F81P-7000-KB	F81Z-7000-KBRM
F2TP-7000-AGA	F2TZ-7V000-AGRM	F4UP-7000-BA	F4UZ-7V000-CRM	F6UP-7000-EA	F6UZ-7V000-EARM	F81P-7000-LB	F81Z-7000-LBRM
						F81P-7000-PB	F81Z-7000-PBRM

FOR REFERENCE PURPOSES ONLY - CHECK VEHICLE APPLICATION LISTING FOR SPECIFIC MOTORCRAFT PART NUMBER

# CROSS REFERENCE TRANSMISSIONS



**GENUINE PARTS**



**Motorcraft**

ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER	ENGINEERING NUMBER	SERVICE NUMBER
<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>		<b>FORD — Cont'd</b>	
F81P-7000-TA .....	F81Z-7000-TARM	F8UP-7000-KA .....	F8UZ-7000-KARM	XC3P-7000-LA .....	F81Z-7000-LBRM	XL3P-7000-JA .....	XL3Z-7000-JARM
F83P-7000-CA .....	F83Z-7000-CBRM	F8UP-7000-LA .....	F8UZ-7000-LARM	XC3P-7000-MA .....	F81Z-7000-TARM	XL3P-7000-KA .....	XL3Z-7000-KARM
F83P-7000-CB .....	F83Z-7000-CBRM	F8UP-7000-LB .....	F8UZ-7000-LBRM	XF1P-7000-AA .....	XF1Z-7000-AARM	XL3P-7000-LA .....	XL3Z-7000-LARM
F83P-7000-DA .....	F83Z-7000-DBRM	F8UP-7000-LC .....	F8UZ-7000-LCRM	XF1P-7000-BA .....	XF1Z-7000-BARM	XL5P-7000-AA .....	XL5Z-7000-AARM
F83P-7000-DB .....	F83Z-7000-DBRM	F8UP-7000-MB .....	F8UZ-7000-MBRM	XF1P-7000-BB .....	XF1Z-7000-BBRM	XL5P-7000-BA .....	XL5Z-7000-BARM
F85P-7000-AA .....	F85Z-7000-AARM	F8UP-7000-NA .....	F8UZ-7000-NARM	XF1P-7000-CA .....	XF1Z-7000-CARM	XL5P-7000-CA .....	XL5Z-7000-CARM
F85P-7000-BA .....	F85Z-7000-BARM	F8UP-7000-PA .....	F8UZ-7000-PARM	XF1P-7000-DA .....	XF1Z-7000-DARM	XL5P-7000-DA .....	XL5Z-7000-DARM
F85P-7000-CA .....	F85Z-7000-CARM	F8UP-7000-RA .....	F8UZ-7000-RARM	XF1P-7000-DB .....	XF1Z-7000-DBRM	XL5P-7000-EA .....	XL5Z-7000-EARM
F85P-7000-DA .....	F85Z-7000-DARM	F8UP-7000-SA .....	F8UZ-7000-SARM	XF1P-7000-EA .....	XF1Z-7000-EARM	XL7P-7000-AA .....	XL7Z-7000-AARM
F85P-7000-EA .....	F85Z-7000-EARM	F8UP-7000-VA .....	F8UZ-7000-VARM	XF1P-7000-EB .....	XF1Z-7000-EBRM	XR3P-7000-AA .....	XR3Z-7000-AARM
F85P-7000-FA .....	F85Z-7000-FARM	F8VP-7000-AA .....	F8VZ-7000-AARM	XF1P-7000-FA .....	XF1Z-7000-FARM	XR3P-7000-BA .....	XR3Z-7000-BARM
F85P-7000-GA .....	F85Z-7000-GARM	F8VP-7000-BA .....	F8VZ-7000-BARM	XF2P-7000-AA .....	XF2Z-7000-AARM	XS4P-7000-CF .....	1S4Z-7000-CARM
F85P-7000-HA .....	F85Z-7000-HARM	F8ZP-7000-AA .....	F8ZZ-7000-AARM	XF2P-7000-BA .....	XF2Z-7000-BARM	XS4P-7000-DF .....	1S4Z-7000-DARM
F87P-7000-AA .....	F87Z-7000-AARM	F8ZP-7000-BA .....	F8ZZ-7000-BARM	XF3P-7000-AA .....	XF3Z-7000-AARM	XW1P-7000-BA .....	XW1Z-7000-BARM
F87P-7000-BA .....	F87Z-7000-BARM	RMXF3P-7000-AC .....	XF3Z-7000-ACRM	XF3P-7000-AB .....	XF3Z-7000-ACRM	XW1P-7000-CA .....	XW1Z-7000-CARM
F88P-7000-AA .....	F88Z-7000-AARM	RMXF3P-7000-BC .....	XF3Z-7000-BCRM	XF3P-7000-AC .....	XF3Z-7000-ACRM	XW1P-7000-DA .....	XW1Z-7000-DARM
F88P-7000-BA .....	F88Z-7000-BARM	XC2P-7000-AA .....	XC2Z-7000-AARM	XF3P-7000-BA .....	XF3Z-7000-BARM	XW4P-7000-AC .....	YW4Z-7000-AARM
F8AP-7000-AA .....	F8AZ-7000-AARM	XC2P-7000-BA .....	XC2Z-7000-BARM	XF3P-7000-BB .....	XF3Z-7000-BCRM	XW4P-7000-BA .....	YW4Z-7000-BARM
F8AP-7000-BA .....	F8AZ-7000-BARM	XC2P-7000-CA .....	XC2Z-7000-CARM	XF3P-7000-BC .....	XF3Z-7000-BCRM	XW4P-7000-BC .....	YW4Z-7000-BARM
F8DP-7000-AA .....	F8DZ-7000-AARM	XC2P-7000-FA .....	F8UZ-7000-FARM	XL1P-7000-AA .....	XL1Z-7000-EARM	XW7P-7000-CA .....	XW7Z-7000-AARM
F8DP-7000-BA .....	F8DZ-7000-BARM	XC2P-7000-HB .....	F8UZ-7000-HARM	XL1P-7000-BA .....	XL1Z-7000-FARM	XW7P-7000-DA .....	XW7Z-7000-AARM
F8DP-7000-CA .....	F8DZ-7000-CARM	XC2P-7000-JB .....	F8UZ-7000-EARM	XL1P-7000-CB .....	XL1Z-7000-CBRM	YL8P-7000-AB .....	YL8Z-7000-ABRM
F8DP-7000-DA .....	F8DZ-7000-DARM	XC2P-7000-LB .....	F8UZ-7000-KARM	XL1P-7000-DB .....	XL1Z-7000-DBRM	YL8P-7000-BA .....	YL8Z-7000-BCRM
F8DP-7000-EA .....	F8DZ-7000-EARM	XC2P-7000-MA .....	XC2Z-7000-MARM	XL2P-7000-AA .....	XL2Z-7000-AARM	YL8P-7000-CA .....	YL8Z-7000-CARM
F8DP-7000-FA .....	F8DZ-7000-FARM	XC2P-7000-NA .....	XC2Z-7000-NARM	XL2P-7000-BA .....	XL2Z-7000-BARM	YL8P-7000-DA .....	YL8Z-7000-DARM
F8LP-7000-AA .....	F8LZ-7000-AARM	XC2P-7000-RA .....	F8UZ-7000-PARM	XL2P-7000-CA .....	XL2Z-7000-CARM	YL8P-7000-EA .....	YL8Z-7000-EARM
F8OP-7000-AA .....	F8OZ-7000-AARM	XC2P-7000-SA .....	XC2Z-7000-SARM	XL2P-7000-DA .....	XL2Z-7000-DARM	YL8P-7000-FA .....	YL8Z-7000-FARM
F8OP-7000-BA .....	F8OZ-7000-BARM	XC2P-7000-UA .....	F8UZ-7000-RARM	XL2P-7000-EA .....	XL2Z-7000-EARM	YW4P-7000-AA .....	YW4Z-7000-AARM
F8UP-7000-AA .....	F8UZ-7000-PARM	XC3P-7000-BA .....	F81Z-7000-ABRM	XL2P-7000-FA .....	XL2Z-7000-FARM	YW4P-7000-BA .....	YW4Z-7000-BARM
F8UP-7000-BA .....	F8UZ-7000-BARM	XC3P-7000-CA .....	F81Z-7000-BBRM	XL3P-7000-AA .....	XL3Z-7000-AARM	FA03-19090-K .....	F5CZ-7000-AARM
F8UP-7000-CA .....	F8UZ-7000-CARM	XC3P-7000-DA .....	F81Z-7000-DBRM	XL3P-7000-BA .....	XL3Z-7000-BARM	FU0B-19090-G .....	F62Z-7000-BRM
F8UP-7000-DA .....	F8UZ-7000-DARM	XC3P-7000-EA .....	F81Z-7000-EBRM	XL3P-7000-CA .....	XL3Z-7000-CARM	FU6J-19090-W .....	FOCZ-7000-BRM
F8UP-7000-EA .....	F8UZ-7000-EARM	XC3P-7000-FA .....	F81Z-7000-FBRM	XL3P-7000-DA .....	XL3Z-7000-DARM	FU6V-19090-N .....	FOCZ-7000-AARM
F8UP-7000-FA .....	F8UZ-7000-FARM	XC3P-7000-GA .....	F81Z-7000-GBRM	XL3P-7000-EA .....	XL3Z-7000-EARM	FU6V-19090-R .....	FOCZ-7000-AARM
F8UP-7000-GA .....	F8UZ-7000-GARM	XC3P-7000-HA .....	F81Z-7000-HBRM	XL3P-7000-FA .....	XL3Z-7000-FARM	FU9A-19090-S .....	F32Z-7000-AARM
F8UP-7000-HA .....	F8UZ-7000-HARM	XC3P-7000-JA .....	F81Z-7000-PBRM	XL3P-7000-GB .....	XL3Z-7000-GBRM	GF01-19090-E .....	F62Z-7000-BRM
F8UP-7000-JA .....	F8UZ-7000-JARM	XC3P-7000-KA .....	F81Z-7000-KBRM	XL3P-7000-HB .....	XL3Z-7000-HBRM	GF11-19090-E .....	F62Z-7000-BRM

**FOR REFERENCE PURPOSES ONLY - CHECK VEHICLE APPLICATION LISTING FOR SPECIFIC MOTORCRAFT PART NUMBER**